

Somfy Track Fitting Instructions



Installation Steps (Glydea/Irisimo/Movelite Tracks)

1. **Mark and Drill:** Position brackets (wall or ceiling) at correct locations, ensuring they are spaced no more than 50cm (about 20 inches) apart for stability.

2. **Attach Track:** Fix brackets to the surface, then snap or screw the rail into the brackets.

3. **Install Motor:**
 - Unlock the motor by rotating the locking lever.
 - Insert the motor shaft into the drive pulley hole on the track.
 - Lock the motor into place by rotating the locking lever back.
 - *Note: The motor can be installed on either side of the track.*

4. **Final Checks:** Ensure the drive belt is properly aligned and the carriers move freely