


Installation and User Manual

January 2016

EN



Electric Curtain Track System

Silent Gliss® 5600

Content

1	General Overview.....	3
1.1	User information	3
1.2	Intended use / Guarantee	3
1.3	Other applicable documents	3
1.4	Safety instructions	3
1.5	Maintenance, inspection and repair tips.....	3
2	Transportation, Storage.....	3
2.1	Transportation	3
2.2	Storage	3
3	Installation	3
3.1	Installation instructions, aids and personal protection	3
3.2	Motorisation.....	3
3.3	Unpacking	4
3.4	System handling	4
3.5	Overhead and wall installation	4
4	Maintenance	4
4.1	Repairs / Inspection.....	4
4.2	Cleaning	4
4.3	Care hints for fabrics	4
4.4	Disposal.....	4
5	EU Conformity	4
6	Scale drawing	5
7	Overhead installation.....	5
7.1	With clamp.....	5
7.2	Direct mounting (drilling through profile - not possible with Standard Wave gliders)	7
7.3	With recess profile	7
8	Wall installation.....	8
9	Installation with connecting bridge SG 10831 (For tracks supplied in 2 or more parts)	9
10	Programming	10
10.1	Manual programming	10
10.2	Automatic programming	11
11	Wiring diagram	13
11.1	Motorisation.....	13
11.2	Main Switching	13
11.3	Low Voltage Switching	13
12	Faults and troubleshooting	14

1 General Overview

1.1 User information

The Operating and Installation Instructions help to acquaint you with the product and its possible applications. They contain important tips to support the correct and safe operation of the product. Please retain a copy of this manual.

It is to be read, understood and adhered to by each person who works with or on the system in the following tasks: installation, operation, maintenance and cleaning, troubleshooting.

This manual does not replace your **personal responsibility** as fitter or operator.

1.2 Intended use / Guarantee

The product is intended for use exclusively in accordance with these specifications and this manual, i.e. for: **Internal shading of windows (no outdoor installation).**

A different use or use beyond this scope is not considered intended use. The manufacturer / supplier is not liable for any resulting damage. Non-compliance releases Silent Gliss from its liability.

The guarantee excludes faults that are not attributable to material or fabrication faults, but have arisen as a result of incorrect operation by the purchaser or improper care or other personal negligence. Troubleshooting measures falling outside of the guarantee will be carried out by Silent Gliss or another appropriate retailer at the cost of the purchaser.

1.3 Other applicable documents

Every product supplied includes documents that are a component part of the operating and installation instructions: *safety instructions, scale drawing, installation instructions.*

1.4 Safety instructions

The relevant safety laws in the country of operation must be adhered to.

The following tips or symbols are used throughout:



Warning - risk of injury! Highlights possible hazards from mechanical workings which could lead to injury or even death.



Use eye protection! Eye protections must be worn during all drilling work.



General warning sign! Highlights general information.

The product may be installed only in a faultless condition (no transportation damage, etc.) and only as intended, in awareness of safety and hazards and in accordance with all tips in this manual.

Faults that could impair safety and functionality must be repaired.

The user (end customer) must have read and understood the operating instructions after installation and operational start-up are completed.

1.5 Maintenance, inspection and repair tips



Work must only be carried out by qualified specialists.

2 Transportation, Storage

2.1 Transportation



The product may be transported only in suitable and sufficient protective packaging (manufacturer's packaging).

Curved products (rails, etc.) require wooden crating.

Waste and packaging material is to be disposed of in line with local regulations.

Keep packaging material out of the reach of children. Packing sheets, Styrofoam pieces and other small parts can be dangerous for children to play with.

2.2 Storage



Products and their accessories are to be stored in suitable packaging in dust-free spaces with normal humidity.

3 Installation

3.1 Installation instructions, aids and personal protection



Local safety regulations must be observed during installation of the product (stable ladders, etc.).

3.2 Motorisation



Electrical installation must be carried out by a certified electrician in accordance with the legal regulations and standards of the relevant country.

3.3 Unpacking



Unpack components carefully
Waste and packaging material is to be disposed of in line with local regulations. Keep packaging material out of the reach of children. Packing sheets, Styrofoam pieces and other small parts can be dangerous for children to play with. Check delivery items against delivery note.

3.4 System handling



Please note the following during unpacking and installation: a) do not cause contamination from unwashed hands. b) do not allow moisture to get on the fabric. c) avoid causing kinks and snags (e.g. by dragging over surfaces and edges).

3.5 Overhead and wall installation



During installation, window handles and other protruding items and fittings must not impair the function of the product. The fixing material should be chosen to suit the background. The fitter is responsible for selecting the correct fixing materials.

Check: Raise and lower blind and check correct winding and square hanging of the fabric.

4 Maintenance

4.1 Repairs / Inspection



Any repair work required by the system may only be carried out by authorised specialists. Only original replacement parts may be used for repairs.

4.2 Cleaning



The product and its components, such as mouldings end caps, etc., must not be treated with aggressive cleaning products. It is best cleaned with a slightly damp cloth. For heavier soiling, warm water with a neutral, non-abrasive cleaning product (pH-neutral domestic washing-up liquid) may be used.

4.3 Care hints for fabrics



Washable!



Do not tumble dry



Do not iron!



Do not dry clean!



Do not bleach!

4.4 Disposal




The product must be disposed of in line with local waste disposal regulations for industrial waste.

5 EU Conformity





EU conformity has been certified. This documentation can be requested from Silent Gliss.









6 Scale drawing







7 Overhead installation

7.1 With clamp
















7.2 Direct mounting (drill through) **(not possible with Standard Wave gliders)**





7.3 With recess profile











8 Wall installation





9 Installation with connecting bridge SG 10831 (For tracks supplied in 2 or more parts)










Warning | When installing tracks with Wave gliders the pilots must **not** be moved until fitted, moving the pilots & gliders when upside down can promote the glider cord getting tangled within the glider channel.

Note: Once the connecting bridge is in place and the belt connected with the overlap arm the motor limits **must** be set see section 10

10 Programming

10.1 Manual programming






5

Using 0997 setting lead

1.


Push button in one direction until desired end position is reached. (Minimum movement in first direction must exceed 500 mm)



6

2.

Push button in other direction until the second end position is reached.



7

3.



Push button in first direction until system stops.


Limits can also be set using the same procedure with:








Standard radio wall switch

Dry contacts

Hand held transmitter






11 Wiring diagram

11.1 Motorisation




The electrical installation must be performed by a qualified electrician in accordance with legal regulations and norms of each country.

11.2 Main Switching



11.3 Low Voltage Switching



11.4 Faults and troubleshooting

Possible fault	Possible cause	Elimination of fault
... the motor with permanent power supply rotates in the wrong direction		Replace the 6-pin connector cable from pin 2 to pin 3
... the motor with non-permanent power supply rotates in the wrong direction		Replace the cable from pin 1 and 3 on the power plug
... during group circuit via power line no motor turns		Verify on each motor that the phase connections Pin 1 and 3 are connected in phase
... the motor with permanent or non-permanent power supply does not rotate		Program the end positions again to ensure that the end positions are programmed
... the motor cannot be programmed with the radio transmitter		Make sure that the radio transmitter is programmed
... the motor moves when approaching the intermediate position to the end stop?		Reprogram the intermediate position
... the motor stops again after a short start-up	System is not assembled correctly	Check system Reprogram the end positions

www.silentgliss.com/worldwide